


MAGNUM Joint Compounds

Architectural/Product Specifications

<p>Joint Treatment Materials</p> <ol style="list-style-type: none">1. Magnum Ready Mixed Premier, All purpose, Topping, and Taping in standard and lightweights.2. Magnum Dry Powder All Purpose, Topping, and Taping in standard and lightweights.3. Magnum Surebond Quick Sets (20,45,90 min) lightweights. <p>The contractor should supply all labor and materials required to complete acceptable applications of compound. Upon request, contractors should supply sample work. When approved this shall be the standard for finish to be provided for the job.</p> <p>General Conditions</p> <p>During cold weather provide thermostatically controlled heat of 55° F Minimum temperature until completely dry. Adequate ventilation should be provided at all times for proper drying. Unless otherwise indicated, Magnum Products can be used with all interior gypsum wallboards where moisture is unlikely to become a factor. Surface preparation should meet minimum Gypsum Assoc. requirements with framework meeting Hud/FHA/ALSC and local codes.</p>	<p>Magnum Joint Compounds</p> <p>Material should be Magnum joint compounds in original unopened containers bearing the name of the manufacturer and the published directions for use. All material should be stored in moderate temperatures, out of direct sunlight.</p> <p>Application</p> <p>Joint compound should be applied in accordance with printed instructions on the container or packaging.</p> <p>Apply a uniform layer, 4" wide, of all purpose, taping or Surebond. Center tape and embed into the compound leaving sufficient compound under the tape for adhesion.</p> <p>Allow adequate time to thoroughly dry, or the proper amount of time for Surebond to set, then apply fill coat approximately 4" wider and feathered at edge. After thoroughly dry or setting, apply another coat of all purpose, topping, or Surebond, slightly wider than the second coat, so as to leave a level uniform surface after sanding.</p> <p>All inside corners shall be taped as above. After thoroughly drying or setting, add at least one coat of all purpose.</p>	<p>Metal cornerbead shall be finished with at least two applications of all purpose, topping, or Surebond (topping not to be used for first application over metal). Feathered edges should extend 10" to 12" from nose of corner.</p> <p>Drywall fasteners should be finished with at least two applications of all purpose, topping, or Surebond so as to leave a smooth uniform surface after sanding.</p> <p>Caution should be used when sanding so as not to rough the wallboard paper to the extent that painting will not hide joints, corners, or fasteners. A good quality sealer must be applied prior to painting or texturing. Final wallboard finish should comply with the five levels of finish approved by the Gypsum Assoc., Painting and Decorating Contractors of America, and the Drywall Finishing Council.</p> <p></p> <p>P.O. BOX 15868 LENEXA, KS 66285-5868 (913) 888-0882</p>
--	--	--